


# NeoBuds Pro

True Wireless Stereo Earbuds with Active Noise Cancellation

Download EDIFIER CONNECT APP from the APP store/Google Play Store

For user safety and compliances, also for the optimum performance, please carefully read safety instructions and use the product in accordance with them.

## 1. Product description and accessories




Accessories: Ear tips x 7 pairs, Storage bag x1, Charging cable x1

Note:

- There are different size of ear tips attached in the package, please select the suitable ones to wear.
- Images are for illustrative purposes only and may differ from the actual product.
- For the need of technical improvement and system upgrade, information and specifications contained herein may be slightly different from actual product. If any difference is found, the actual product prevails.

## 2. Power on/off

- The earbuds will power on when the case is opened.
- The earbuds will power off when placed in the case and the case is closed.



## 3. Charge

### • Charge the earbuds


- Place the earbuds in the case and close the case for charging.

### • Charge the charging case

- Connect the case to power source with the included charging cable for charging.
- When the case is being charged, the indicators will be lit one by one from center to sides, and then turn off one by one from sides to center in a breathing pattern; After the case is fully charged, the indicators will turn off.

### • Battery level indicator on the charging case

- Open/close the charging case will auto-show its battery level: Red LED indicators will all be lit from center to sides and then extend to light up from center to sides, and turn off in 3 seconds. The length of the indicators bar means battery level.
- **Low battery level of the charging case:** When opening/closing the case, if the red indicators bar flash five times rapidly and then turn off it means the case is at low battery level, please charge the case in time.



Input:

5V  $\equiv$  200mA (earbuds)


5V  $\equiv$  1A (charging case)

Warning:

- The rechargeable batteries that provide power for this product must be disposed properly for recycling. Do not dispose of batteries in fire to prevent an explosion.
- The power source used must be approved by relative departments and in accordance with electrical specifications of devices as well as local regulatory requirements (e.g. UL, CSA, VDE, CCC), otherwise there may be dangers of fire, explosion, etc.

## 4. User guide

### • Bluetooth connection



- Place the earbuds in the case, press and hold the button on the case for around 3 seconds to enter Bluetooth pairing, and the indicators on the case will be lit one by one from left to right in a circulating pattern;
- Set mobile phone to search for and connect to "EDIFIER NeoBuds Pro", after pairing is successful, the whole indicator bar will flash red twice and then turn off.


### • TWS pairing of the left and right earbuds & clear pairing records

Place the earbuds in the case, triple click the button on the case to enter the TWS pairing of the left and right earbuds and to clear pairing records, and the indicators on the case will be lit one by one from sides to center in a circulating pattern; After the TWS pairing is successful, the earbuds will auto-enter Bluetooth pairing state, and the indicators on the case will be lit one by one from left to right in a circulating pattern until the pairing is done.

Note:

For initial use, please set mobile phone to search for and connect to this product after the charging case is opened and the indicators on the case flash from left to right; For subsequent use, the earbuds will auto-connect to the mobile phone used last time.

### • Functional operation




- Accept/end a call: double click the left or right earbud
- Mode switch: double click the left earbud
- Game mode on/off: triple click the left earbud
- Pause/play: double click the right earbud
- Next track: triple click the right earbud

Note:


- Mode switch: It is the high noise cancellation mode & ambient sound mode by default when both earbuds are used. The users can select the low noise cancellation mode & ambient sound mode or the standard mode & ambient sound mode through the EDIFIER CONNECT APP; It will auto-enter the standard mode & ambient sound mode when only one earbud is used.
- The users can customize buttons function through the EDIFIER CONNECT APP.
- The product may be updated from time to time without prior notice.

### • Tap



## Operating method: Tap! Tap! Tap!

The right method to tap: The users cannot "touch" but can "tap" the earbuds! Please tap within the effective tapping area with fingertip as shown in the image below. The users can also adjust the tapping sensitivity through the EDIFIER CONNECT APP.



**Double click the left earbud:**  
accept/end a call  
mode switch

**Triple click the left earbud:**  
game mode

**Double click the right earbud:**  
accept/end a call  
pause/play

**Triple click the right earbud:**  
next track

## 5. FAQs

### ■ When charging the charging case, the indicator is off .

- Please ensure the charging case is correctly connected with power source.

### ■ No sound.

- Check if the earbuds are operating.
- Check if the earbuds volume are at an appropriate level.
- Check if the earbuds are correctly connected with mobile phone.
- Check if the earbuds are operating within a normal working range.

### ■ The call quality of the earbuds are not good.

- Check if mobile phone is in an area with strong signal.
- Please ensure the earbuds are within effective distance (10m) and no obstacle between the earbuds and mobile phone.

### ■ When playing music, cannot control pause/play/next track via the earbuds.

- Please ensure the paired device support AVRCP (Audio/Video Remote Control Profile) profile.

### ■ The tapping function is too sensitive or not sensitive.

- Please ensure you are tapping within the effective area with a moderate intensity or at an appropriate angle. You can also adjust to a desired tapping sensitivity through the EDIFIER CONNECT APP.

### ■ After one earbud alone is connected to another mobile phone, there is no sound from the other earbud when used again.

- When one earbud alone is connected to another mobile phone, the interconnection between the left and right earbuds may have been disconnected. To restore the two earbuds mode, triple click the button on the case to resume interconnection between the left and right earbuds. Then try again.

### ■ There is a delay problem when playing game.

- Please triple click the left earbud to switch to game mode and then start playing game.

## 6. Maintenance

- If it is not used for long periods of time, please charge the product with lithium battery every three months.
- Keep the product away from humid places to avoid affecting internal circuit. Do not use the product during intense exercise or with much sweat to prevent sweat from dropping into the product to make damage.
- Do not put the product in places exposed to sun or with high temperature. High temperature will shorten service life of electronic components, damage battery and make plastic components deformed.
- Do not put the product in cold places to avoid damaging internal circuit board.
- Do not dismantle the product. Non-professional personnel may damage the product.
- Do not drop, strongly vibrate, strike the product with hard object to avoid damaging internal circuit.
- Do not use drastic chemicals or cleaner to clean the product.
- Do not use sharp objects to scratch product surface to avoid damaging shell and affecting facade.

Model: EDF200051

Edifier International Limited  
P.O. Box 6264  
General Post Office  
Hong Kong

www.edifier.com

© 2021 Edifier International Limited. All rights reserved.  
Printed in China

NOTICE:

For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice.

Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product. If any difference is found, the actual product prevails.